

WM-DD10

SERVICE MANUAL

West Germany Model

This model is almost the same as the model WM-DDI previously produced.
Therefore, see the WM-DDI service manual for the information not contained
in this service manual.

PARTS LIST (The difference between WM-DDI and WM-DD10)

Page	WM-DDI		WM-DD10	Description
	Ref No.	Part No.	Part No.	
11	1	X-3310-967-1	X-3310-990-1	(RED) CASE ASSY
	1	X-3310-968-1	X-3310-992-1	(SILVER).....CASE ASSY
	1	X-3310-969-1	X-3310-991-1	(BLACK) CASE ASSY
	3	*3-324-445-01	(supplied with CASE ASSY)	(SILVER, RED).....LABEL, MODEL NUMBER
	3	*3-324-445-11		(BLACK) LABEL, MODEL NUMBER
	13	X-3310-964-1	X-3310-988-1	(SILVER).....LID ASSY, CASSETTE
	13	X-3310-965-1	X-3310-989-1	(BLACK) LID ASSY, CASSETTE
	13	X-3310-966-1	X-3310-987-1	(RED) LID ASSY, CASSETTE
	901	A-3070-220-A	A-3070-283-A	MOUNTED PCB, AUDIO
15		*3-324-441-01 3-769-606-11	*3-343-554-01 3-750-888-11	INDIVIDUAL CARTON MANUAL, INSTRUCTION

• Items marked "*" are not stocked since they
are seldom required for routine service. Some
delay should be anticipated when ordering these
items.



9-953-994-11

Sony Corporation
Audio Group

STEREO CASSETTE PLAYER
SONY®

English
8910407-1
Printed in Japan
© 1989.9

Published by Customer Relations and Service Group.